



WELD THE WORLD

Cruiser Power Pulse

322
402
502

Instruction manual



ENG



Antwerpsesteenweg 949 9041 Gent - Oostakker
info@welda.be | T +32 (0)9 355 74 26
www.welda.be | F +32 (0)9 355 92 01



INDEX

| | | |
|-----------|---------------------------------------------------|-----------|
| 1 | INTRODUCTION | 4 |
| 1.1 | INTRODUCTION | 5 |
| 2 | INSTALLATION | 6 |
| 2.1 | CONNECTIONS TO THE ELECTRICAL MAINS NETWORK | 6 |
| 2.2 | FRONT PANEL..... | 6 |
| 2.3 | REAR PANEL..... | 7 |
| 2.4 | PREPARING FOR MMA WELDING | 8 |
| 2.5 | PREPARING FOR TIG WELDING | 9 |
| 3 | USER INTERFACE | 10 |
| 4 | UNIT POWER-UP | 12 |
| 5 | RESET (LOAD FACTORY SETTINGS)..... | 12 |
| 6 | ALARM MANAGEMENT | 13 |
| 7 | WELDING | 15 |
| 7.1 | MMA WELDING/MMA CEL | 15 |
| 7.2 | ARC AIR (ELECTRODE GOUGING)..... | 16 |
| 7.3 | TIG DC WELDING | 17 |
| 8 | TORCH TRIGGER PROCEDURE | 18 |
| 9 | TECHNICAL DATA | 19 |
| 9.1 | CRUISER 322 – POWER PULSE 322..... | 19 |
| 9.2 | CRUISER 402 – POWER PULSE 402..... | 20 |
| 9.3 | CRUISER 502 – POWER PULSE 502..... | 21 |
| 10 | ELECTRICAL DIAGRAM | 23 |
| 10.1 | CRUISER 322 - POWER PULSE 322..... | 23 |
| 10.2 | CRUISER 402/502 - POWER PULSE 402/502..... | 29 |
| 10.3 | “REMOTE 1” CONNECTOR | 34 |
| 10.4 | “IR” CONNECTOR | 34 |
| 10.5 | REMOTE CONTROL CONNECTOR (back panel)..... | 34 |
| 11 | SPARE PARTS | 36 |
| 11.1 | CRUISER 322 - POWER PULSE 322..... | 36 |
| 11.2 | CRUISER 402/502 - POWER PULSE 402/502..... | 38 |

ENGLISH

1 INTRODUCTION

| | | |
|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|--|-------------------|
| | | IMPORTANT! |
| <p><i>This handbook must be consigned to the user prior to installation and commissioning of the unit. Read the "General prescriptions for use" handbook supplied separately from this handbook before installing and commissioning the unit.</i></p> | | |
| <p><i>The meaning of the symbols in this manual and the associated precautionary information are given in the "General prescriptions for use".</i></p> | | |
| <p><i>If the "General prescriptions for use" are not present, it is mandatory to request a replacement copy from the manufacturer or from your dealer.</i></p> | | |
| <p><i>Retain these documents for future consultation.</i></p> | | |

LEGEND

| | |
|---------------------------------------------------------------------------------------------------------------|--------------------|
| | DANGER! |
| <p><i>This pictogram warns of danger of death or serious injury.</i></p> | |
| | WARNING! |
| <p><i>This pictogram warns of a risk of injury or damage to property.</i></p> | |
| | CAUTION! |
| <p><i>This pictogram warns of a potentially hazardous situation.</i></p> | |
| | INFORMATION |
| <p><i>This pictogram gives important information concerning the execution of the relevant operations.</i></p> | |

- ➔ This symbol identifies an action that occurs automatically as a result of a previous action.
- ⓘ This symbol identifies additional information or a reference to a different section of the manual containing the associated information.
- § This symbol identifies a reference to a chapter of the manual.
- *1 The symbol refers to the associated numbered note.

NOTES

The figures in this manual are purely guideline and the images may contain differences with respect to the actual equipment to which they refer.

1.1 INTRODUCTION

This professional and rugged welding power source for DC MMA and TIG welding with exceptional arc characteristics is designed to operate in harsh environmental conditions in the fields of professional maintenance, shipyards and offshore, building construction and heavy fabrication.

The combination of digital control and excellent welding with cellulosic electrodes is ideal for hydraulic applications and welding work on oil pipelines and in the petrochemical industry.

The ARC AIR function allows perfect de-seaming with carbon electrodes of up to 10mm in diameter.
Up to 6 mm diameter electrode welding is possible in MMA.

In MMA welding the Hot Start and Arc Force functions are adjustable and they allow improved arc striking, a flatter bead and more uniform weld.

The Anti Sticking function makes it possible to detach the electrode rapidly from the workpiece in the event of accidental sticking.

Thanks to its modular configuration, the power source can be configured for MIG/MAG welding by adding a wire feed unit, extension, and, if required, a cooling unit and power source transport trolley.

Fan. The fan is turned on only during welding, at the end of the welding process it remains on for a fixed period of time according to welding conditions.

The fan is nonetheless controlled by specific thermal sensors that guarantee a correct cooling of the machine.

Accessories/ancillary devices that can be connected to the unit:

- Manual remote controller for remote adjustment of the welding current.
- Foot-pedal remote controller for TIG torch arc striking and remote adjustment of welding current.
- Remote control for use with welding robot (combined with power source and wire feeder).
- Power source trolley.
- Power source trolley for multi-function configuration (MIG/MAG).
- Tool compartment.
- Liquid cooler for MIG/MAG-TIG torches.
- Wire feeder.

Consult your dealer for an updated list of accessories and the latest new products available.


ENGLISH

2 INSTALLATION



DANGER! *Lifting and positioning*

Read the warnings highlighted by the following symbols in the "General prescriptions for use".




2.1 CONNECTIONS TO THE ELECTRICAL MAINS NETWORK

The mains power supply features to which the equipment should be connected are given in chapter "12 TECHNICAL DATA" at page 54.

The machine can be connected to motorgenerators provided their voltage is stabilised.


Connect/disconnect the various devices with the machine switched off.

2.2 FRONT PANEL



- Remote controller connector [Item 1].
- Negative pole welding socket [Item 2].
- Positive pole welding socket [Item 3].
- Welding power source ON/OFF switch. Item 4].
- Mains protection ON LED [Item 5]. This LED illuminates if an incorrect operating condition occurs:
 - absence of a phase in the power supply line.

2.3 REAR PANEL



- Auxiliary power supply transformer safety fuse [Item 1].
 - Type: Delayed acting (T)
 - Amperage: 2 A (3.15 A for 322)
 - Voltage: 500 V a.c.
- Power cable [Item 2].
 - Total length (including internal part): 5,0 m
 - Number and cross section of wires: 4 x 6 mm² (4 mm² on 322)
 - Power plug type: not supplied
- Pre-heater supply socket (OPTIONAL on 322) [Item 3].
The socket is internally protected by a self-resetting fuse.
 - Power socket type: Schuko
 - Maximum power: 130 W
 - Voltage: 230 V a.c.
- Socket for connecting the power cable between the power source and the remote control device [Item 4].
- Cooler group power feeding connector [Item 5].
 - Voltage: 400 V a.c.
 - Current output: 1.0 A
 - IP protection rating: IP20 (cap open) / IP66 (cap closed)



DANGER!
High voltage!

If the socket is not connected to any devices always close cap 1

- (Only Power Pulse 322/402/502) Connector for connection to the programmer [Item 6]. Program-

ENGLISH

ming connector for the “pulsed” circuit board. You can update the software of the equipment using the programming kit.

- Connector of the bundle of cables for connecting the power source to the remote control device. [Item 7].
- Signals connector for automatic application [Item 8].

2.4 PREPARING FOR MMA WELDING

1. Set the welding power source ON/OFF switch to “O” (unit switched off).
2. Plug the power cable plug into a mains socket outlet.
3. Choose the electrode based on the type of material and thickness of the workpiece to be welded.
4. Insert the electrode in the electrode holder.
5. Connect the electrode holder cable to the welding socket based on the polarity requested by the type of electrode used.
6. Connect the plug of the ground clamp to the welding socket on the basis of the polarity required.
7. Connect the earth clamp to the workpiece being processed.



DANGER!

Electric shock hazard!

Read the warnings highlighted by the following symbols in the “General prescriptions for use”.



8. Set the welding power source ON/OFF switch to “I” (unit powered).
 9. Select the following welding mode on the user interface: MMA
 10. Set the required welding parameter values on the user interface.
- When the remote controller [RC] is connected and the relative locking screw is tightened, welding current can be adjusted using the remote controller.

The system is ready to start welding.

| REAR VIEW | FRONT VIEW (polarity to basic electrode) |
|-----------|---------------------------------------------|
| | |


2.5 PREPARING FOR TIG WELDING

1. Set the welding power source ON/OFF switch to "O" (unit de-energized).
 2. Plug the power cable plug into a mains socket outlet.
 3. Choose the electrode based on the type of material and thickness of the workpiece to be welded.
 4. Insert the electrode in the TIG torch.
 5. Connect the torch plug to the welding socket on the basis of the polarity required by the type of electrode in question.
 6. Connect the plug of the ground clamp to the welding socket on the basis of the polarity required.
 7. Connect the earth clamp to the workpiece being processed.
 8. Set the welding power source ON/OFF switch to "I" (unit powered).
 9. Select the following welding mode on the user interface: DC TIG
- ① This model of welding machine has not been provided either with the control for gas flow (sole-nozzle valve) or with the torch trigger.

The system is ready to start welding.

LIFT-ARC WELDING


1. Open the torch valve to let the gas out.
 2. Touch the workpiece with the torch electrode.
 3. Slowly lift the torch to strike the arc.
- The WELDING CURRENT reaches the preset value.
4. Quickly distance the torch from the workpiece to extinguish the welding arc.
 5. Close the torch valve to interrupt the gas flow.




ENGLISH

3 USER INTERFACE

Cruiser 322 - Power Pulse 322



Cruiser 402-502 - Power Pulse 402-502



| CODE | SYMBOL | DESCRIPTION |
|------|--------|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| L1 | | This LED illuminates to confirm the presence of power on the output sockets. |
| L2 | | This LED illuminates to show an anomaly in the operating conditions. |
| L3 | | Illuminates to indicate a value in the following unit of measurement: AMPERES (A) |
| L4 | | Illuminates to indicate a value in the following unit of measurement: VOLTS (V) |
| L5 | | Illuminates to signal activation of a connected remote control unit, if available. |
| L6 | | This LED indicates that the current reference setting is imposed by the remote controller. |
| L7 | | This LED illuminates to show that the following welding mode is selected: MMA |
| L8 | | This LED illuminates to show that the following welding mode is selected: DESEAMING MODE |
| L9 | | This LED illuminates to show that the following welding mode is selected: CONTINUOUS DC TIG |
| L10 | | This LED illuminates to show that the following welding mode is selected: GOUGING ELECTRODE (Only on 402-502) |
| D1 | | Data setting: The display shows the acronym of the parameter to be set. Welding: The display shows the effective amperes or volts value during welding. |
| S1 | | Welding: This button selects the parameter to be shown on the following display: D1 Possible choices: (A) Effective welding current - (V) Effective welding voltage Parameters/functions setting: This button selects the parameter to be shown on the following display: D1 Possible choices: (A) Effective welding current - (V) Effective welding voltage |
| S2 | | Press and release: the button enables the device to receive the welding current control signal from a remote controller. Hold down for 3 seconds: the button activates a connected remote controller, if available, which is then used to manage all functions of the welding power source from a distance. |
| S3 | | This button selects the welding mode. |
| POT1 | | MMA: The potentiometer sets the value of the following parameter: HOT START |
| POT2 | | MMA: The potentiometer sets the value of the following parameter: ARC FORCE |
| E1 | | Data setting: The encoder sets the value of the selected parameter. Welding: The encoder sets the value of the following parameter: WELDING CURRENT |

ENGLISH

4 UNIT POWER-UP

Set the welding power source ON/OFF switch to "I" to switch on the unit.
AL.H. The message appears on the following display: **D1**.


First power-up or power-ups following a RESET procedure

The welding power source sets up for welding with the factory pre-sets.

Subsequent power-ups

The welding power source sets up for welding in the latest stable welding configuration that was active at the time of power-off.

5 RESET (LOAD FACTORY SETTINGS)



The reset procedure involves complete restoration of the default values, parameters and memory settings set in the factory.

The reset procedure is useful in the following cases:

- Too many changes made to the welding parameters so user finds it difficult to restore defaults.
- Unidentified software problems that prevent the welding power source from functioning correctly.

| | |
|------------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| (A) | <ul style="list-style-type: none">○ Set the welding power source ON/OFF switch to "O" to switch the unit off.○ Keeping both the S2 and S3 buttons pressed, set the generator power source switch to "I" to turn on the equipment [! SIMULTANEOUS ACTIONS]<ul style="list-style-type: none">- rEC : The message appears on the following displays: D1.- Wait for the memory clear procedure to terminate. |
|------------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|

6 ALARM MANAGEMENT

 This LED illuminates if an incorrect operating condition occurs.
An alarm message appears on the following display: **D1**.

Tab. 1 - Alarm messages



| MESSAGE | MEANING | EVENT | CHECKS |
|----------|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| AL. HEA. | In start-up phase | Appears for 2-3 seconds | |
| | Overheating alarm Indicates tripping of the welding power source thermal protection. Leave the unit running so that the overheated components cool as rapidly as possible. When the unit has cooled, the welding power source will reset automatically. | All functions disabled. <u>Exceptions:</u> <ul style="list-style-type: none"> • Cooling fan. • Cooler (if switched on). | <ul style="list-style-type: none"> • Make sure that the power required by the welding process is lower than the maximum rated power output. • Check that the operating conditions are in compliance with the welding power source data plate specifications. • Check for the presence of adequate air circulation around the welding power source. |
| | Phase missing alarm Indicates the absence of a phase in the power supply line. The message appears at the same time as the mains protection activation LED switches on. | All functions disabled. <u>Exceptions:</u> <ul style="list-style-type: none"> • Cooling fan. | <ul style="list-style-type: none"> • Check if the equipment power supply line has all the phases. <u>If the problem persists:</u> • qualified technical personnel are required for repair/maintenance jobs. |
| AL. Coo. | Cooler alarm Indicates insufficient pressure in the torch liquid cooling circuit. | All functions disabled. <u>Exceptions:</u> <ul style="list-style-type: none"> • Cooling fan. <p>The alarm message persists on the display until the first operation is performed on the user interface. <u>Signalling of the alarm depends on the following settings:</u></p> <ul style="list-style-type: none"> • Coo = on: the alarm is signalled if the cooling unit is connected to the power source and if it is running. • Coo = off: the alarm is never signalled, irrespective of the circumstances. • Coo = Aut: the alarm is signalled if the cooling unit is connected to the power source and if it is running. | <ul style="list-style-type: none"> • Check that the connection to the cooler is correct. • Check that the "O/I" switch is set to "I" and that it illuminates when the pump is running. • Check that the cooler is filled with coolant. • Check that the cooling circuit is liquid tight, notably the torch hoses, the fuse and the internal connections of the cooler. |
| E. 69 | Software compatibility error Indicates that the welding power source has a software version that is not compatible with the remote device connected to it (remote controller, wire feed unit). | All functions disabled. <u>Exceptions:</u> <ul style="list-style-type: none"> • Cooling fan. | <ul style="list-style-type: none"> • Update the remote device software. • Contact support |

ENGLISH

| MESSAGE | MEANING | EVENT | CHECKS |
|----------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|-------------------------------------------------------------------------------------------------------------------------------------------------|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| E. 04 | Alarm, no-load voltage failure | All functions disabled. <u>Exceptions:</u> <ul style="list-style-type: none">• Cooling fan | <ul style="list-style-type: none">• Check to ensure the welding torch is not resting on the work-piece connected to ground.• Check that when the power source is switched on there is no short circuit between the sockets (voltage must be greater than/equivalent to U_r). <p><u>If the problem persists:</u></p> <ul style="list-style-type: none">• Qualified technical personnel are required for repair/maintenance jobs. |
| CAn Err. | No communication alarm Indicates the presence of problems in data communication between the power source and wire feeder. When the unit has cooled, the welding power source will reset automatically. Exit the alarm state by performing one of the following actions: Switch the power source off. | All functions disabled. <u>Exceptions:</u> <ul style="list-style-type: none">• cooling fan.• cooler (if switched on). | <ul style="list-style-type: none">• Check that the connecting cable between power source and wire feeder is intact and make sure the connectors are securely tightened. <p><u>If the problem persists:</u></p> <ul style="list-style-type: none">• qualified technical personnel are required for repair/maintenance jobs. |

7 WELDING

7.1 MMA WELDING/MMA CEL



Tab. 2 - Parameters of the 1st level menu: MMA/MMA CEL mode

| SETTING | MIN | DEFAULT | MAX | NOTES |
|-----------------------------------------------------------|------|---------|-------|-------------------------------------------------------------------------------------------------------------|
| WELDING CURRENT MAXIMUM CURRENT WITH REMOTE CONTROLLER | 10 A | 80 A | MAX A | MAX: Maximum value of welding current |
| HOT-START | 0 % | - | 100 % | The value is calculated as a percentage of the preset welding current. The value is limited to 250A max. |
| ARC FORCE | 0 % | - | 250 % | The value is calculated as a percentage of the preset welding current. |

ENGLISH

- WELDING CURRENT

- This parameter regulates the primary welding current value.

- MAXIMUM CURRENT WITH REMOTE CONTROLLER

- The maximum output current value that can be achieved with foot pedal controller external reference.

- HOT-START

- This parameter aids electrode melting at the time of arc striking. It is set as a percentage referred to the value of the following parameter: **WELDING CURRENT**. The value is limited to 250A max.

- Consequences of a higher value:

- Ease of activation; Greater starting spatter; increase in the activation area.

- Consequences of a lower value:

- Difficulty of activation; Less starting splatter; Reduction in the activation area.

- ARC FORCE

- This parameter helps to avoid electrode sticking during welding. It is set as a percentage referred to the value of the following parameter: **WELDING CURRENT**


- Consequences of a higher value:

- Fluency factors in welding; Arc welding stability; Increased melting of the electrode within the workpiece; More weld spatter.


- Consequences of a lower value:

- The arc is extinguished more easily, less welding spatter.

7.2 ARC AIR (ELECTRODE GOUGING)




- Press the **S3** (◎) button to activate the ELECTRODE GOUGING mode.




The parameters are automatically set to their maximum values. The value cannot be adjusted.

7.3 TIG DC WELDING



- Press the **S3** (◎) button to activate the CONTINUOUS DC TIG mode.




Tab. 3 - Parameters of the 1st level menu: CONTINUOUS DC TIG mode

| SETTING | MIN | DEFAULT | MAX | NOTES |
|-----------------|-----|---------|-------|---------------------------------------|
| WELDING CURRENT | 5 A | 80 A | MAX A | MAX: Maximum value of welding current |

8 TORCH TRIGGER PROCEDURE

- 2 STROKE LIFT:

- Touch the workpiece with the torch electrode.
- Press (1T) and keep the torch trigger pressed.
- Slowly lift the torch to strike the arc.
- The welding current reaches the pre-set value, by way of an up slope time, if programmed.
- Release (2T) the trigger to start the weld completion procedure.
- The current reaches the end current value in the time set in the down slope time parameter.
- The arc is extinguished.
- Gas delivery continues for the time set in the post gas parameter.



9 TECHNICAL DATA

| | |
|-------------------------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Directives applied | Waste electrical and electronic equipment (WEEE) |
| | Electromagnetic compatibility (EMC) |
| | Low voltage (LVD) |
| | Restriction of the use of certain hazardous substances (RoHS) |
| Construction standards | EN 60974-1; EN 60974-10 Class A |
| Conformity markings |  Equipment compliant with European directives in force |
| |  Equipment suitable in an environment with increased hazard of electric shock |
| |  Equipment compliant with WEEE directive |
| |  Equipment compliant with RoHS directive |

9.1 CRUISER 322 – POWER PULSE 322

| | | | | |
|---------------------------------------------|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|-------------------------------------------------------------------------------------|--------------------------------|---------------------------------|
| Supply voltage | 3 x 400 V a.c. ± 15 % / 50-60 Hz | | | |
| Mains protection | 25 A 500 V Delayed | | | |
| Zmax | This equipment complies with IEC 61000-3-12 provided that the maximum permissible system impedance is less than or equal to 27 mΩ at the interface point between the user's supply and the public system. It is the responsibility of the installer or user of the equipment to ensure, by consultation with the distribution network operator if necessary, that the equipment is connected only to a supply with maximum permissible system impedance less than or equal to 27 mΩ. | | | |
| Dimensions (L x D x H) | 690 x 290 x 450 mm | | | |
| Weight | 45 kg | | | |
| Insulation class | H | | | |
| Protection rating | IP23 | | | |
| Cooling | AF: Air-over cooling (fan assisted) | | | |
| Maximum gas pressure | 0,5 MPa (5 bar) | | | |
| Static characteristic | MMA |  | Falling characteristic | |
| | TIG |  | Falling characteristic | |
| | MIG/MAG |  | Flat characteristic | |
| Welding mode | | MMA | TIG | MIG/MAG |
| Current and voltage adjustment range | | 10 A / 20.4 V 300 A - 32.0 V | 5 A / 10.2 V 320 A - 22.8 V | 10 A / 14.5 V 320 A / 30.0 V |
| Welding current / Working voltage | 40% (40° C) | -- | -- | -- |
| | 60% (40° C) | 300 A - 32.0 V | 320 A - 22.8 V | 320 A / 30.0 V |
| | 100% (40° C) | 250 A - 30.0 V | 260 A - 20.4 V | 260 A / 27.0 V |
| Maximum input power | 40% (40° C) | -- | -- | -- |
| | 60% (40° C) | 14.3 kVA – 11.0 kW | 11.6 kVA – 8.5 kW | 15.2 kVA – 11.6 kW |
| | 100 % (40° C) | 11.4 kVA – 8.7 kW | 8.8 kVA – 6.4 kW | 11.6 kVA – 8.5 kW |
| Maximum supply current | 40% (40° C) | -- | -- | -- |
| | 60% (40° C) | 20.9 A | 16.6 A | 22.0 A |
| | 100 % (40° C) | 16.7 A | 12.7 A | 16.5 A |
| Maximum Effective Supply Current | 40% (40° C) | -- | -- | -- |
| | 60% (40° C) | 16.2A | 12.8 A | 17.0 A |
| | 100 % (40° C) | 16.7 A | 12.7 A | 16.5 A |

ENGLISH

| | | |
|------------------------------|--|------|
| No-load voltage (U0) | | 73 V |
| Reduced no-load voltage (Ur) | | 10 V |

9.2 CRUISER 402 – POWER PULSE 402

| | | | | |
|---------------------------------------------|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|------------------------------------------------------------------------------------------------------------|--------------------------------|---------------------------------|
| Supply voltage | 3 x 400 V a.c. ± 15 % / 50-60 Hz | | | |
| Mains protection | 32 A 500 V Delayed | | | |
| Zmax | This equipment complies with IEC 61000-3-12 provided that the maximum permissible system impedance is less than or equal to 27 mΩ at the interface point between the user's supply and the public system. It is the responsibility of the installer or user of the equipment to ensure, by consultation with the distribution network operator if necessary, that the equipment is connected only to a supply with maximum permissible system impedance less than or equal to 27 mΩ. | | | |
| Dimensions (L x D x H) | 690 x 290 x 450 mm | | | |
| Weight | 49.5 kg | | | |
| Insulation class | H | | | |
| Protection rating | IP23 | | | |
| Cooling | AF: Air-over cooling (fan assisted) | | | |
| Maximum gas pressure | 0,5 MPa (5 bar) | | | |
| Static characteristic | MMA |  Falling characteristic | | |
| | TIG |  Falling characteristic | | |
| | MIG/MAG |  Flat characteristic | | |
| Welding mode | | MMA | TIG | MIG/MAG |
| Current and voltage adjustment range | | 5 A / 20.2 V 400 A / 36.0 V | 5 A / 10.2 V 400 A / 26.0 V | 20 A / 15.0 V 400 A / 34.0 V |
| Welding current / Working voltage | 50% (40° C) | -- | -- | -- |
| | 60% (40° C) | -- | -- | -- |
| | 100% (40° C) | 400 A / 36.0 V | 400 A / 26.0 V | 400 A / 34.0 V |
| Maximum input power | 50% (40° C) | -- | -- | -- |
| | 60% (40° C) | -- | -- | -- |
| | 100 % (40° C) | 18.4 kVA – 16.8 kW | 14.3 kVA – 12.9 kW | 17.7 kVA – 16.1 kW |
| Maximum supply current | 50% (40° C) | -- | -- | -- |
| | 60% (40° C) | -- | -- | -- |
| | 100 % (40° C) | 25.5 A | 18.4 A | 24.3 A |
| Maximum Effective Supply Current | 50% (40° C) | -- | -- | -- |
| | 60% (40° C) | -- | -- | -- |
| | 100 % (40° C) | 25.5 A | 18.4 A | 24.3 A |
| No-load voltage (U0) | | 83V | | |
| Reduced no-load voltage (Ur) | | 9V | | |


9.3 CRUISER 502 – POWER PULSE 502

| | | | | |
|---------------------------------------------|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|---------------------------------|--------------------------------|---------------------------------|
| Supply voltage | 3 x 400 V a.c. ± 15 % / 50-60 Hz | | | |
| Mains protection | 40 A 500 V Delayed | | | |
| Zmax | This equipment complies with IEC 61000-3-12 provided that the maximum permissible system impedance is less than or equal to 49 mΩ at the interface point between the user's supply and the public system. It is the responsibility of the installer or user of the equipment to ensure, by consultation with the distribution network operator if necessary, that the equipment is connected only to a supply with maximum permissible system impedance less than or equal to 49 mΩ. | | | |
| Dimensions (L x D x H) | 690 x 290 x 450 mm | | | |
| Weight | 49.5 kg | | | |
| Insulation class | H | | | |
| Protection rating | IP23 | | | |
| Cooling | AF: Air-over cooling (fan assisted) | | | |
| Maximum gas pressure | 0.5 MPa (5 bar) | | | |
| Static characteristic | MMA | Falling characteristic | | |
| | TIG | Falling characteristic | | |
| | MIG/MAG | Flat characteristic | | |
| Welding mode | | MMA | TIG | MIG/MAG |
| Current and voltage adjustment range | | 10 A / 20.4 V 500 A / 40.0 V | 5 A / 10.2 V 500 A / 30.0 V | 20 A / 15.0 V 500 A / 39.0 V |
| Welding current / Working voltage | 30% (40° C) | 500 A / 40.0 V | 500 A / 30.0 V | 500 A / 39.0 V |
| | 60% (40° C) | 450 A / 38.0 V | 460 A / 28.4 V | 450 A / 36.5 V |
| | 100% (40° C) | 400 A / 36.0 V | 400 A / 26.0 V | 400 A / 34.0 V |
| Maximum input power | 30% (40° C) | 24.3 kVA – 22.2 kW | 18.2 kVA – 16.6 kW | 23.7 kVA – 21.7 kW |
| | 60% (40° C) | 21.2 kVA – 19.0 kW | 16.1 kVA – 14.5 kW | 20.3 kVA – 18.3 kW |
| | 100 % (40° C) | 18.1 kVA – 15.9 kW | 13.0 kVA – 11.4 kW | 17.5 kVA – 15.3 kW |
| Maximum supply current | 30% (40° C) | 35.1 A | 26.3 A | 34.3 A |
| | 60% (40° C) | 30.0 A | 22.8 A | 28.5 A |
| | 100 % (40° C) | 25.5 A | 18.4 A | 24.3 A |
| Maximum Effective Supply Current | 30% (40° C) | 24.8 A | 18.6 A | 24.2 A |
| | 60% (40° C) | 23.2 A | 17.7 A | 22.1 A |
| | 100 % (40° C) | 25.5 A | 18.4 A | 24.3 A |
| No-load voltage (U0) | | 83V | | |
| Reduced no-load voltage (Ur) | | 9V | | |




10 ELECTRICAL DIAGRAM


10.1 CRUISER 322 - POWER PULSE 322




ENGLISH

A







ENGLISH



C




10.2 CRUISER 402/502 - POWER PULSE 402/502





ENGLISH

A




B






C




D

ENGLISH


10.3 "REMOTE 1" CONNECTOR



10.4 "IR" CONNECTOR




10.5 REMOTE CONTROL CONNECTOR (back panel)



ENGLISH

11 SPARE PARTS


11.1 CRUISER 322 - POWER PULSE 322



| N° | CODE | DESCRIPTION |
|----|---------------|-----------------------------------------------|
| 1 | 014.0002.0008 | KNOB WITH CAP + INDICATOR |
| 2 | 014.0002.0016 | KNOB WITH CAP |
| 3 | 013.0023.0601 | FRONT PANEL LABEL |
| 4 | 050.5143.0000 | COMPLETE LOGIC FRONT PANEL |
| 5 | 016.0009.0003 | RUBBER FOOT |
| 6 | 011.0013.0020 | LOWER COVER |
| 7 | 012.0007.0020 | PLASTIC LOUVRE |
| 8 | 012.0007.0010 | FRONT/REAR PLASTIC PANEL |
| 9 | 011.0013.0021 | FRONT/REAR PLATE |
| 10 | 016.4107.0001 | LED HOLDER |
| 11 | 022.0002.0190 | LED WIRING |
| 12 | 040.0001.0017 | THREE-POLE SWITCH |
| 13 | 021.0001.0279 | OUTPUT SOCKET |
| 14 | 011.0013.0038 | FRONT SOCKETS PLATE |
| 15 | 050.0001.0111 | OUTPUT BOARD |
| 16 | 045.0006.0085 | (-) DIODE COPPER BRACKET |
| 17 | 045.0006.0084 | (+) DIODE COPPER BRACKET |
| 18 | 022.0002.0224 | REMOTE LOGIC BOARD WIRING |
| 19 | 011.0013.0039 | LEFT TUNNEL SUPP. PLATE |
| 20 | 045.0006.0098 | HALL SENSOR COPPER BRACKET |
| 21 | 011.0013.0041 | HALL SUPPORT PLATE |
| 22 | 041.0004.0501 | HALL EFFECT SENSOR |
| 23 | 040.0003.1080 | TERMAL SWITCH 80°C L=130mm |
| 24 | 032.0002.2403 | ISOTOP DIODE |
| 25 | 045.0006.0071 | (-/+) DIODE COPPER BRACKET |
| 26 | 045.0006.0088 | DIODES-TRANSFORMER COPPER BRACKET |
| 27 | 045.0006.0086 | DIODES-MODULE SHORT BRACKET |
| 28 | 050.0003.0044 | SNUBBER BOARD |
| 29 | 011.0013.0037 | COVER PANEL SUPPORT PLATE |
| 30 | 011.0000.0911 | LEFT COVER |
| 31 | 040.0003.1002 | TERMAL SWITCH 75°C L=200mm |
| 32 | 050.0001.0119 | PRIMARY CAPACITOR BOARD |
| 33 | 050.0001.0112 | OUTPUT FILTER BOARD |
| 34 | 011.0000.0921 | RIGHT COVER |
| 35 | 050.0003.0036 | COMPLETE POWER BOARD |
| 36 | 050.0001.0140 | BUS BOARD |
| 37 | 016.0010.0001 | BOARDS SUPPORT GUIDE |
| 38 | 050.0002.0057 | POWER SUPPLY CONTROL BOARD |
| 39 | 050.0002.0052 | SUPPLIES BOARD |
| 40 | 050.0028.0080 | PULSE BOARD (ONLY 322 POWER PULSE VERSION) |
| 41 | 012.0000.0005 | PLASTIC COVER HANDLE TUBE SUPPORT PLATE |

| N° | CODE | DESCRIPTION |
|----|---------------|------------------------------------------------------|
| 42 | 011.0009.0047 | HANDLE TUBE SUPPORT PLATE |
| 43 | 016.0002.0001 | PIN |
| 44 | 011.0013.0013 | HANDLE TUBE |
| 45 | 011.0000.0901 | UPPER COVER |
| 46 | 050.0002.0068 | LINE FILTER BOARD |
| 47 | 041.0006.0006 | TOROIDAL TRANSFORMER |
| 48 | 050.0001.0147 | LINE FILTER BOARD |
| 49 | 011.0013.0044 | BOARD SUPPORT PLATE |
| 50 | 011.0013.0023 | UPPER PLATE |
| 51 | 011.0013.0034 | REAR PLATE |
| 52 | 022.0002.0156 | 17 PIN CABLE |
| 53 | 022.0002.0284 | 10 PIN CONNECTOR CABLE (ONLY POWER PULSE VERSION) |
| 54 | 021.0005.0001 | 230V SOCKET |
| 55 | 013.0000.7000 | REAR PANEL |
| 56 | 016.0011.0002 | PLASTIC CAP |
| 57 | 045.0000.0017 | COMPLETE CABLE CLAMP |
| 58 | 021.0014.0303 | RS-232 CONNECTOR CAP |
| 59 | 021.0004.2993 | 10 PIN CONNECTOR CAP |
| 60 | 045.0002.0014 | SUPPLY CABLE |
| 61 | 021.0013.0007 | ILME CONNECTOR CAP |
| 62 | 022.0002.0073 | CU SUPPLY CABLE |
| 63 | 016.0011.0004 | FUSE HOLDER CAP |
| 64 | 040.0006.1880 | FUSE HOLDER |
| 65 | 022.0002.0152 | RS-232 CABLE |
| 66 | 011.0014.0069 | COVER PLATE (2) |
| 67 | 012.0007.0040 | CAP |
| 68 | 011.0013.0040 | RIGHT TUNNEL SUPP. PLATE |
| 69 | 011.0013.0032 | VENTILATION SHROUD |
| 70 | 003.0002.0017 | FAN |
| 71 | 011.0013.0033 | INTERNAL FAN SUPPORT |
| 72 | 044.0004.0027 | OUTPUT INDUCTOR |
| 73 | 042.0003.0041 | POWER TRANSFORMER |
| 74 | 015.0001.0017 | HEAT SINK |
| 75 | 040.0007.1315 | FUSE |
| 76 | 021.0004.2994 | 17 PIN CONNECTOR CAP |

11.2 CRUISER 402/502 - POWER PULSE 402/502



| N° | CODE | DESCRIPTION | N° | CODE | DESCRIPTION |
|----|---------------|-----------------------------------|----|---------------|----------------------------------------------------|
| 1 | 014.0002.0008 | KNOB WITH CAP + INDICATOR | 38 | 044.0004.0022 | INPUT INDUCTOR |
| 2 | 014.0002.0016 | KNOB WITH CAP | 39 | 011.0013.0033 | INTERNAL FAN SUPPORT |
| 3 | 013.0018.1001 | FRONT PANEL LABEL (502) | 40 | 011.0000.0921 | RIGHT COVER PANEL |
| | 013.0018.0901 | FRONT PANEL LABEL (402) | 41 | 003.0002.0017 | FAN |
| 4 | 032.0001.8216 | THREE PHASE RECTIFIER BRIDGE | 42 | 011.0013.0032 | VENTILATION SHROUD |
| 5 | 016.0010.0001 | BOARDS SUPPORT GUIDE | 43 | 011.0013.0040 | RIGHT TUNNEL SUPP. PLATE |
| 6 | 012.0007.0010 | FRONT/REAR PLASTIC PANEL | 44 | 011.0013.0034 | REAR PLATE |
| 7 | 011.0013.0021 | FRONT/REAR PLATE | 45 | 030.0017.2202 | RESISTOR |
| 8 | 040.0001.0016 | THREE-POLE SWITCH | 46 | 012.0007.0040 | CAP |
| 9 | 011.0013.0038 | FRONT SOCKETS PANEL | 47 | 011.0014.0069 | COVER PLATE (2) |
| 10 | 011.0013.0041 | HALL SUPPORT PLATE | 48 | 013.0000.7000 | REAR PANEL |
| 11 | 011.0013.0039 | LEFT TUNNEL SUPP. PLATE | 49 | 040.0006.1880 | FUSE HOLDER |
| 12 | 040.0003.1007 | THERMAL CUT-OUT | 50 | 016.0011.0004 | FUSE HOLDER CAP |
| 13 | 032.0002.2403 | ISOTOP DIODE | 51 | 022.0002.0073 | C.U. POWER SUPPLY WIRING |
| 14 | 045.0006.0090 | DIODES-TRANSFORMER COPPER BRACKET | 52 | 021.0013.0007 | ILME CONNECTOR CAP |
| 15 | 045.0006.0091 | ISOTOP/SOCKET COPPER BRACKET | 53 | 045.0002.0009 | SUPPLY CABLE |
| 16 | 045.0006.0089 | DIODE-DIODE BRACKET | 54 | 021.0004.2994 | 17 PIN CONNECTOR CAP |
| 17 | 050.0001.0112 | OUTPUT FILTER BOARD | 55 | 021.0005.0001 | 230V SOCKET |
| 18 | 050.0002.0054 | COMPLETE POWER BOARD | 56 | 021.0014.0303 | RS-232 CONNECTOR CAP |
| 19 | 050.0002.0057 | POWER SUPPLY CONTROL BOARD | 57 | 045.0000.0017 | CABLE CLAMP |
| 20 | 050.5080.0000 | COMPLETE FRONT LOGIC PANEL (502) | 58 | 016.0011.0002 | CAP Ø=13 |
| | 050.5079.0000 | COMPLETE FRONT LOGIC PANEL (402) | 59 | 022.0002.0152 | RS-232 CABLE |
| 21 | 050.0001.0105 | SNUBBER BOARD | 60 | 022.0002.0284 | 10 PIN CONNECTOR CABLE (ONLY POWER PULSE VERSION)" |
| 22 | 011.0013.0037 | COVER PANEL SUPPORT PLATE | 61 | 022.0002.0240 | 17 PIN CABLE |
| 23 | 011.0000.0911 | LEFT COVER PANEL | 62 | 011.0013.0023 | UPPER PLATE |
| 24 | 012.0007.0020 | PLASTIC LOUVRE | 63 | 050.0002.0061 | FAN AND C.U. CONTROL BOARD |
| 25 | 016.4107.0001 | LED HOLDER | 64 | 041.0006.0006 | AUXILIARY TRANSFORMER |
| 26 | 022.0002.0190 | LED WIRING | 65 | 050.0002.0053 | MAINS FILTER BOARD |
| 27 | 021.0001.0279 | OUTPUT SOCKET | 66 | 031.1005.0228 | CAPACITOR |
| 28 | 022.0002.0239 | REMOTE LOGIC CABLE | 67 | 011.0000.0901 | UPPER COVER |
| 29 | 041.0004.0501 | HALL EFFECT SENSOR | 68 | 050.0002.0052 | SUPPLIES BOARD |
| 30 | 050.0001.0111 | OUTPUT FILTER BOARD | 69 | 050.0003.0055 | BUS BOARD |
| 31 | 045.0006.0085 | (-) SOCKET COPPER BRACKET | 70 | 050.0021.0080 | PULSE BOARD (ONLY 402 POWER PULSE VERSION) |
| 32 | 045.0006.0084 | (+) SOCKET COPPER BRACKET | | 050.0022.0080 | PULSE BOARD (ONLY 502 POWER PULSE VERSION) |
| 33 | 015.0001.0017 | HEAT SINK | 71 | 021.0004.2993 | 10 PIN CONNECTOR CAP |
| 34 | 042.0003.0042 | POWER TRANSFORMER | 72 | 045.0006.0098 | HALL SENSOR COPPER BRACKET |
| 35 | 016.0009.0003 | RUBBER FOOT | 73 | 040.0007.1200 | FUSE |
| 36 | 011.0013.0020 | LOWER COVER | | | |
| 37 | 044.0004.0016 | OUTPUT INDUCTOR | | | |





WELD THE WORLD



Antwerpsesteenweg 949 9041 Gent - Oostakker
info@welda.be | T +32 (0)9 355 74 26
www.welda.be | F +32 (0)9 355 92 01